

MASCOT 3 in 1 Portable Cot



Thank you for purchasing this quality Babylove product from our exclusive range of baby products. We are confident that you will appreciate its many highlights including durability and reliability. Your new product has been manufactured to comply with the Australian Standard AS/NZS 2195:1999 and comes with a 12 month warranty (receipt required). Please keep this instruction manual for future reference.

Distributed by Nursery Elegance Pty Ltd
ACN 122 443 387
Unit 10, 339 Williamstown Road Port Melbourne VIC 3207, Australia
PHONE 1300 131 477
WEB: www.babylove.com.au
EMAIL: info@Babylove.com.au

INSTRUCTION MANUAL

KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE

BEFORE ASSEMBLING THIS COT READ AND UNDERSTAND THE INSTRUCTIONS. INCORRECT ASSEMBLY MAY MAKE THE COT UNSAFE. KEEP THESE INSTRUCTIONS IN A SAFE PLACE FOR FUTURE REFERENCE.

WARNINGS

- Never leave your child unattended.
- Do not use your cot if any part is broken, torn or missing.
- Do not use or leave the cot near open fires, naked flames, electric bar fires, gas fires, stoves, heaters or barbecues.
- Do not place the cot where your child could reach medication, money, string, elastic, small toys or other small objects.
- Do not place the cot near trailing cords, leads or flexes such as cords or electrical leads, etc.
- Do not use additional mattress or padding.
- Do not place toys or other objects in the cot which could provide a step or foothold to help the child climb out.
- Cots with padded rails should not be used if the covered fabric is torn or bitten through.
- Do not use parts or accessories except those tested and approved by Babylove.
- Always check that the folding parts are fully locked before using the cot.
- Do not place more than one child in the cot at the same time.
- Do not use this cot with a child who can climb out, weighs more than 15kg, or is taller than 90cms.
- When using a fitted sheet it must fit the mattress tightly.
- Check that the assembly of the cot is correct and safe.
- The thickness of the mattress has been specified to ensure that the distance from the top of the mattress to the top of the lowest side or end will always be at least 500mm. This will reduce the risk of children falling out of the cot.
- Always check parts regularly for tightness of screws, nuts and other fasteners - tighten if required.
- Use only the mattress supplied with the cot.
- Do not use an additional mattress, padding, toys or other objects in the cot which would help your child fall out.
- Using the wrong size mattress may create hazardous gaps that could result in suffocation or could reduce the side height of the cot, which may result in your child falling out of the cot.

THIS PRODUCT IS NOT INTENDED FOR COMMERCIAL USE.

CARE AND MAINTENANCE

To prolong the life of your nursery product keep it clean and do not leave it in the direct sunlight for extended periods of time.

Removable fabric covers and trims may be cleaned using warm water with a household soap or a mild detergent. Allow it to dry fully, preferably away from the direct sunlight.

DO NOT DRY CLEAN, OR USE BLEACH.

Do not machine wash, tumble or spin dry, unless the care labelling on the product permits these methods.

Non removable fabric covers and trims may be cleaned using a damp sponge with soap or mild detergent. Allow it to dry completely before folding or storing it away.

In some climates the covers and trims may be affected by mould and mildew. To help prevent this occurring, do not fold or store the product if it is damp or wet. Always store the product in a well ventilated area.





To maintain the safety of your nursery product, seek prompt repairs for bent, torn, worn or broken parts. Use only those parts and accessories tested and approved by Babylove.

WARNING: IF THE SIDES DO NOT LATCH FIRMLY OR THERE ARE HOLES IN THE MESH SIDES, DISCONTINUE USE IMMEDIATELY AND SEEK REPAIR.

Mattress by Babylove	- series R032MAS
Bassinet by Babylove	- series R032MAS
Change Table by Babylove	- series R032MAS

6. TO USE THE MESH NET

- A Position the mesh net in the Portable Cot as shown.
- B Locate the clamps onto the side rails with the 'hooks' facing inwards
- C Extend the mesh over either end of the Portable Cot.






WARNING - MATTRESS SIZE

This cot is made for a mattress which is 740mm wide, 1000mm long and no more than 25mm thick. Using the wrong size mattress may create hazardous gaps that could result in suffocation or could reduce the side height of the cot which may result in your child falling out from the cot.

For its correct use, ensure you follow these instructions in the order that they are written.

PARTS LIST

- A 1 - Carry bag
- B 1 - Mattress
- C 4 - Mattress Support Rods
- D 1 - Cot
- E 1 - Bassinette
- F 1 - Change Table
- G 1 - Mesh net



1. TO OPEN THE COT

THESE STEPS WILL ENSURE THAT THE COT IS CORRECTLY OPENED AND READY FOR USE.





- A Unzip the carry bag and remove the cot.
- B Stand the cot on its feet and undo the hook & loop straps that hold the mattress around the frame.
- C Remove the mattress and set other accessories aside.
- D Separate the legs of the cot.
- E Starting with the short rails pull the centre up with both hands quickly until they are locked in place.

(CAUTION: TAKE CARE, AS FINGER PINCHING CAN OCCUR IN THE CORNERS WHEN LOCKING THE RAILS IN PLACE.)

- F Now do the same with the longer rails.

NOTE: ALL THE TOP RAILS SHOULD BE LOCKED IN PLACE. IF THEY ARE NOT, RELEASE THEM AND TRY AGAIN. THE CENTRE OF THE COT BASE MUST BE IN A RAISED POSITION TO ALLOW THE RAILS TO LOCK EASILY. CHECK FOR THE SECURE ENGAGEMENT OF THE RAILS BY PUSHING DOWN ON THEM.

- G Holding one end of the cot clear of the ground, gently press down the handle in the middle of the base until the base lays down flat. The base should now be locked into position.






5. TO USE THE CHANGETABLE (con't)

- C Pick the changetable up by the plastic hooks and connect to the Portable Cot short end rail as shown.
- D Rotate the Changetable over the Portable Cot and engage each of the four clamps onto the side rails. Move the Bassinette clamps slightly if they interfere with attaching the Changetable.

NOTE: MAKE SURE THE FOUR CLAMPS ARE ENGAGED ON TO THE SIDE RAILS.

- E Pull the pocket flap over the end of the Portable Cot. Attach the plastic clamps to the leg tubes to keep the pocket in place.
- F When the Changetable is not in use, always fold over the end rail until required again.
- G To remove the Changetable, release the plastic hooks from the top rails.



4. TO USE THE BASSINET (con't)

- D Snap the 12 plastic clips onto the top rails of the cot. Make sure the plastic clips are positioned against the edge of the corner mouldings.



NOTE: ALWAYS SECURE THE MATTRESS BEFORE USING THE BASSINET.

WARNING: TO PREVENT FALLS, THIS BASSINET SHOULD NOT BE USED ONCE A CHILD CAN SIT UP.

ALWAYS REMOVE THE BASSINET BEFORE FOLDING THE PORTABLE COT.


5. TO USE THE CHANGETABLE

WARNINGS

- NEVER LEAVE CHILD UNATTENDED.
- NEVER PLACE A CHILD IN THE PORTABLE COT WHEN THE CHANGETABLE IS IN USE.
- ALWAYS USE THE HARNESS WHEN USING THE CHANGETABLE.
- ALWAYS FOLD THE CHANGETABLE AWAY WHEN NOT IN USE.

- A Lay the changetable face down with the two plastic hooks facing up.

- B Connect the tubes together on either side of the changetable. Insert one tube end into the other until the pin engages. Pull to make sure they are locked together.



1. TO OPEN THE COT (con't)

- H Place the mattress into the cot with its padded side facing up.
- I Secure the mattress to the cot by passing the loop straps through the slots in the cot base and pressing it into the hook attachment strips, sewn to the underside of the cot base.




NOTE: ALWAYS SECURE THE MATTRESS BEFORE USING THE COT

2. TO USE THE WHEELS

- A Push the brake lever down to lock, or lift the brake lever up to unlock.

NOTE: ALWAYS APPLY THE BRAKES WHEREVER AND WHENEVER YOU ARE USING THE COT.
(Push down to lock) (Lift up to unlock)



3. TO FOLD THE COT



THESE STEPS MUST BE FOLLOWED IN THIS ORDER TO EASILY FOLD THE COT.

IF BASSINET OR CHANGE TABLE ARE FITTED, THEY MUST BE REMOVED BEFORE FOLDING THE COT.

- A Release the loop straps under the base that secure the mattress and remove the mattress from the cot.


3. TO FOLD THE COT (con't)

- B Pull the strap up in the middle of the base and then pull base up approximately 50cm.
- C Release each top rail by lifting the rail slightly and squeezing on the buttons, located in the centre joint. The buttons are located at the centre of each rail.



IF THE TOP RAILS DO NOT FOLD - DO NOT FORCE THEM - LIFT THE BASE HIGHER AND RE SQUEEZE THE BUTTONS TO FULLY RELEASE THEM.

- D Ensure that each rail is fully released and then pull all the way up on the cot base strap, while gathering the legs and the frame together until its fully folded.



DISASSEMBLE AND STORE THE BASSINET AND CHANGE TABLE IN THE CARRY BAG.

- E Take the mattress and wrap it around the folded cot with the padded side facing inwards.
- F Thread the straps through the plastic loops, pull them tight and secure using the hook and loop attachments.
- G Take the carry bag and cover the folded cot. Finish covering the cot and close the zipper, with the mattress handle through the opening.



4. TO USE THE BASSINET

- A Insert the 2, two-piece support rods into bassinet inner sleeves separately, then engage them in the middle.
- B Insert the mattress and secure it to the bassinet by passing the loop straps through the slots in the bassinet base, then press the loop straps onto the hook padding, sewn to the underside of the bassinet.
- C Lower the bassinet within the cot with warning label at short end.

